



CID 2905 Caller ID with Call Reject





Owner's Manual
Please read before using this equipment.

Contents

Important Information	4
Features	8
Preparation	10
Installing Batteries/Setup	10
Adjusting the Display's Contrast	13
Connecting to the Phone Line	13
Connecting to an Answering Machine	14
Mounting the CID	15
Operation	16
Incoming Calls	16
Using Call Reject	17
Message Waiting	17
Reviewing Call Records	18
Caller ID Messages	19
Deleting Caller ID Records	20
Troubleshooting	22
Care	23

© 2001 RadioShack Corporation. All Rights Reserved.
RadioShack and RadioShack.com are trademarks used
by RadioShack Corporation.

WARNING: To reduce the risk of fire or shock hazard, do not expose this product to rain or moisture.

	CAUTION RISK OF ELECTRIC SHOCK. DO NOT OPEN.	
CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER OR BACK. NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED PERSONNEL.		



This symbol is intended to alert you to the presence of uninsulated dangerous voltage within the product's enclosure that might be of sufficient magnitude to constitute a risk of electric shock. Do not open the product's case.



This symbol is intended to inform you that important operating and maintenance instructions are included in the literature accompanying this product.

Important Information

- To use this Caller ID (CID), you must be in an area where Caller ID service is available, and you must subscribe to the service.
- Where Caller ID is offered, one or more of the following options are generally available:
 - caller's number only
 - caller's name only
 - caller's name and number

Your CID displays the caller's name only if that option is available in your area.

- The actual number of Caller ID records your CID will store depends on the amount of Caller ID information sent by the phone company.

Your CID is ETL listed to UL standards and meets all applicable FCC requirements.

FCC INFORMATION

We have designed your CID to conform to federal regulations, and you can connect it to most telephone lines. However, each CID (and each device, such as a telephone or answering machine) that you connect to the telephone line draws power from the line. We refer to this power draw as the device's *ringer equivalence number*, or REN. The REN is on the bottom of your CID.

If you use more than one phone or other device on the line, add up all the RENs. If the total is more than five (three in rural areas), your phones might not ring. If ringer operation is impaired, remove a device from the line.

Your CID complies with Part 68 of the *FCC Rules*. You must, upon request, provide the FCC registration number and the REN to your phone company. Both numbers are on the bottom of the CID.

You must not connect your CID to:

- coin-operated systems
- party-line systems

- most electronic key telephone systems

In the unlikely event that your CID causes problems on the phone line, the phone company can temporarily disconnect your service. If this happens, the phone company attempts to notify you in advance. If advance notice is not practical, the phone company notifies you as soon as possible and advises you of your right to file a complaint with the FCC.

Also, the phone company can make changes to its lines, equipment, operations, or procedures that could affect the operation of this CID. The phone company notifies you of these changes in advance, so you can take the necessary steps to prevent interruption of your phone service.

This CID complies with the limits for a Class B digital device as specified in Part 15 of the *FCC Rules*. These limits provide reasonable protection against radio and TV interference in a residential area. However, your equipment might cause TV or radio interference even when it is operating properly.

To eliminate interference, you can try one or more of the following corrective measures:

- Reorient or relocate the TV or radio's receiving antenna.
- Increase the distance between the CID and the radio or TV.
- Use outlets on different electrical circuits for the equipment and the radio or TV.

Consult your local RadioShack store if the problem continues.

LIGHTNING

Your CID has built-in protection circuits to reduce the risk of damage from surges in telephone and power line current. These protection circuits meet or exceed the FCC requirements. However, lightning striking the telephone or power lines can damage your CID.

Lightning damage is not common. Nevertheless, if you live in an area that has severe electrical storms, we suggest that you unplug your CID when storms approach to reduce the possibility of damage.

Features

Your RadioShack Caller ID displays the caller's telephone number (including name, if available in your area) and the date and time the call was received, as provided by your local phone company to Caller ID service subscribers.

Note: Check with your local phone company regarding name service availability.

Your CID includes these features:

Call Reject — lets you to play a prerecorded message when you receive an unwanted call.

50 Caller ID Memory— stores up to 50 name and number Caller ID records or number only Caller ID records.

Call Counter — shows the number of calls you have received.

New Call Indicator — lets you see at a glance that you have new calls.

Three-Line Display — makes it easy to see the caller information and the current time and date simultaneously.

Message Waiting — tells you when you have received a voice mail message (if you subscribe to the message waiting service from your local phone company).

Note: The Message Waiting feature does not work with stutter dial tone service. Check with your telephone company for the type of service you have.

Trilingual Operation — lets you select English, French, or Spanish as the message display.

Clock — displays the current time and date as provided to Caller ID service subscribers by your local telephone company.

Reviewing Scrolling — lets you easily scroll through all records in Caller ID memory.

Contrast Control — lets you adjust the display contrast to match your preference.

Preparation

INSTALLING BATTERIES/ SETUP

You need three AAA batteries (not supplied) to power your Caller ID (CID). For the longest operation and best performance, we recommend alkaline batteries, available at your local RadioShack store.

Cautions:

- Always use fresh batteries of the required size and recommended type.
- Do not mix old and new batteries, different types of batteries (alkaline, standard, or rechargeable), or rechargeable batteries of different capacities.

Follow these steps to install batteries.

1. Use a flat-blade screwdriver to lift and remove the battery compartment cover.
2. Insert three fresh AAA batteries into the compartment as indicated by the


polarity symbols (+ and –) marked inside.

3. Turn the CID over so you can see the display. After you install the batteries, **SET LANGUAGE** flashes briefly, then **ENGLISH** (the default display language) flashes for about 10 seconds.

Note: If you do not press any button for about 10 seconds, the CID automatically selects English and the time and date appear.

4. To select another language, press **REVIEW ▲**. **FRENCH** flashes. Press **REVIEW ▲** until the desired language flashes.
5. Press **REVIEW ▼** to store the selected language. Or, after about 10 seconds, the CID automatically stores the displayed language. **12:00AM 1/01** appears.

6. Replace the cover.

When  flashes or the display dims, replace the batteries.

Warning: Dispose of old batteries promptly and properly. Do not burn or bury them.

Caution: If you do not plan to use the CID for a month, remove the batteries. Batteries can leak chemicals that can destroy electronic parts.

Notes:

- Before you replace the batteries, have fresh ones on hand. If you do not install new batteries within about 2 minutes after removing the old ones, the CID records and the date and time will be lost. The records cannot be replaced, but the date and time will automatically reset when you receive the next call.
- Unplug the modular line cord from the CID before you replace the batteries.
- To reset the language, hold down **REVIEW ▲** and **▼** until **SET LANGUAGE** flashes briefly then **ENGLISH** flashes on the display. Then repeat Steps 4–5 to set the language.

ADJUSTING THE DISPLAY'S CONTRAST


Your CID has eight display contrast settings (0–7).

Follow these steps to adjust the display's contrast.

1. Hold down **DELETE** and **REVIEW ▼** until **CONTRAST X** (X equals the current contrast setting) appears.
2. Continue to hold down **DELETE** and press **REVIEW ▲** or **▼** to select the desired contrast setting.
3. Release **DELETE**. The date and time appear.


CONNECTING TO THE PHONE LINE

The CID connects to any modular phone jack and your phone. You can also connect it to an answering machine.



1. Disconnect your telephone's line cord from the modular phone line jack and plug it into the CID's **PHONE** jack.
2. Plug one end of the supplied modular line cord into the CID's **LINE** jack.
3. Plug the cord's other end into the modular phone line jack.

CONNECTING TO AN ANSWERING MACHINE



1. Disconnect the modular line cord that connects your answering machine to the modular phone line jack, then plug it into the CID's **PHONE** jack.
2. Plug one end of the supplied modular line cord into the CID's **LINE** jack.
3. Plug the cord's other end into the modular phone line jack.

4. Set your answering machine to answer after two or more rings. This gives the Caller ID time to record the call information that the phone company sends between the first and second rings.

MOUNTING THE CID

You can place the CID on a flat surface, or you can mount it on a wall.

Follow these steps to mount the CID on a wall.

1. Select a location near the phone line jack, then use the round holes in the mounting bracket as a template to mark the mounting screw locations on the wall.
2. Drill two $\frac{1}{8}$ -inch (3.5 mm) holes in the wall at the marked locations.
3. While holding the bracket against the wall, thread a screw (not supplied) through each hole in the bracket, then tighten the screws.
4. Align the slots on the back of the Caller ID with the holes on the bracket. Gently slide the CID downward to secure it.

To remove the bracket from the CID, slide the bracket down then lift and remove it.

Operation

INCOMING CALLS

When you subscribe to Caller ID service from your phone company, the phone company sends the caller's phone number (and name, if available) and the call's time and date between the first and second rings. Your CID receives and displays this information for each call and updates the current date and time. You cannot manually set the date and time.

CALL and the CALL indicator flash when you have an incoming call, and the call record appears for 20 seconds, then the number of new calls appears.

NEW flashes and the NEW CALL indicator flashes to show that you have received new calls since the last time you reviewed the stored records.

USING CALL REJECT

When you receive a call you do not want to answer, press **CALL REJECT**. The CALL REJECT indicator lights and the CID announces “We don’t accept calls of this nature. Please remove our phone number from your calling list. Thank you.”

Note: The CID displays the caller’s phone number until you delete it (see “Deleting Caller ID Records” on Page 20).

MESSAGE WAITING

Note: The message waiting feature does not work with stutter dial tone service. Check with your phone company for the type of service you have.

If you subscribe to the telephone company’s message waiting service and have a voice-mail message waiting, **NEW CALL** and **MESSAGE WAITING** appear on the display. **MESSAGE WAITING** remains on the display until you retrieve the message.

If you are talking on the phone when a call comes in, the incoming call automatically rolls over to message waiting. The phone

company sends the information after you end the current call and **MESSAGE WAITING** appears on the display.

In some areas, callers can block the sending of their Caller ID information. When a caller blocks the Caller ID information, - **PRIVATE CALL-** appears instead of the call information.

REVIEWING CALL RECORDS

Each time you receive a call, your CID stores a record that you can see while you are on the phone, or review later. Your CID saves up to 50 call records, replacing the oldest call record with a new call record.

Each call record includes the call number (order in which the call is received), the time and date of the call, the caller's phone number (if available), and the caller's name (if available).

To review the call records, repeatedly press **REVIEW ▲** or **▼**.

END OF LIST appears when you try to scroll before the first or after the last call record.

Note: The CID shows up to 10 digits of an incoming phone number. If the number is longer, you see only the last 10 digits.

Caller ID Messages

Display (English, French, Spanish)	Description
NEW CALL(S) XX (three languages)	Appears the first time you review a new call record. (XX is the number of new calls.)
-PRIVATE CALL- APPEL PERSONNEL LLAMADA PRIVADA	The caller has blocked the call information from being sent.
END OF LIST FIN DE LIST FIN DE LISTA	Appears when you reach the end of your call records.
-----ERROR----- -----ERREUR----- -----ERROR-----	The call information was garbled, or there was an error during the transmission of call information.
NO CALLS AUCUN APPELS NO LLAMADAS	Appears when you press a REVIEW key if there are no call records in the CID's memory.

Display (English, French, Spanish)	Description
-OUT OF AREA- -HORS ZONE- -FUERA DE AREA-	The caller is not within a Caller ID service area. No call information appears.
MESSAGE WAITING MES. EN ATTENTE MENSAJE ESPERA	Appears when a message is waiting (you must subscribe to your phone company's message waiting service to see this). Note: The message waiting feature does not work with stutter dial tone service.

DELETING CALLER ID RECORDS

Caller ID records remain in memory until you delete them, unless they are lost during battery replacement (see "Installing Batteries/Setup" on Page 10).

To delete an individual call record, repeatedly press **REVIEW** ▲ or ▼ until you see the record you want to delete, then press **DELETE** twice. The record disappears. The next record appears or,

if no other calls are stored, **NO CALLS** appears.

To delete all Caller ID records you have already reviewed, hold down **DELETE** for about eight seconds. **ERASE ALL...** flashes. The time and date appear after all reviewed records have been deleted.

Troubleshooting

If your CID is not working as it should, these suggestions might help you eliminate the problem.

Problem	Suggestions
Display is blank.	Replace the batteries. See "Installing Batteries/Setup" on Page 10.
You have an incoming call, but do not receive any call information.	Someone picked up a telephone on the same phone line before the CID recorded the call record. This is not a malfunction.
	Check that the CID is correctly and securely connected.
	Call your phone company to verify that your Caller ID service is active.

CARE

Keep the CID dry; if it gets wet, wipe it dry immediately. Use and store the CID only in normal temperature environments. Handle the CID carefully; do not drop it. Keep the CID away from dust and dirt, and wipe it with a damp cloth occasionally to keep it looking new.

Modifying or tampering with the CID's internal components can cause a malfunction and invalidate its warranty. If your CID is not performing as it should, take it to your local RadioShack store for assistance. If the trouble is affecting the telephone lines, the phone company can ask you to disconnect your CID until you have resolved the problem.

Limited One-Year Warranty

This product is warranted by RadioShack against manufacturing defects in material and workmanship under normal use for one (1) year from the date of purchase from RadioShack company-owned stores and authorized RadioShack franchisees and dealers. EXCEPT AS PROVIDED HEREIN, RadioShack MAKES NO EXPRESS WARRANTIES AND ANY IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES CONTAINED HEREIN. EXCEPT AS PROVIDED HEREIN, RadioShack SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO CUSTOMER OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED DIRECTLY OR INDIRECTLY BY USE OR PERFORMANCE OF THE PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES RESULTING FROM INCONVENIENCE, LOSS OF TIME, DATA, PROPERTY, REVENUE, OR PROFIT OR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF RadioShack HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

In the event of a product defect during the warranty period, take the product and the RadioShack sales receipt as proof of purchase date to any RadioShack store. RadioShack will, at its option, unless otherwise provided by law: (a) correct the defect by product repair without charge for parts and labor; (b) replace the product with one of the same or similar design; or (c) refund the purchase price. All replaced parts and products, and products on which a refund is made, become the property of RadioShack. New or reconditioned parts and products may be used in the performance of warranty service. Repaired or replaced parts and products are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the product made after the expiration of the warranty period.

This warranty does not cover: (a) damage or failure caused by or attributable to acts of God, abuse, accident, misuse, improper or abnormal usage, failure to follow instructions, improper installation or maintenance, alteration, lightning or other incidence of excess voltage or current; (b) any repairs other than those provided by a RadioShack Authorized Service Facility; (c) consumables such as fuses or batteries; (d) cosmetic damage; (e) transportation, shipping or insurance costs; or (f) costs of product removal, installation, set-up service adjustment or reinstallation.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

RadioShack Customer Relations, 200 Taylor Street, 6th Floor, Fort Worth, TX 76102

We Service What We Sell

12/99

03A01

43-2905

Printed in Malaysia